

Hire Information


A few useful hints and tips to help you get the most out of your Hire Trike:



Drive

DRIVE ENGAGEMENT

1. ROTATE HANDLE TO LINE UP WITH SLOT
2. PUSH DRIVE LEVER FORWARDS UNTIL HANDLE SPRINGS DOWN TO ENGAGE DRIVE




3. Push Drive levers forwards to drive forwards

Reverse

DRIVE DISENGAGEMENT

1. PULL HANDLE UP TO DISENGAGE
2. ROTATE HANDLE TO LOCK




3. Roll backwards by pulling spokes of wheels and controlling direction with steering lever


Parking Brake

PARKING BRAKE APPLICATION

1. PULL BRAKE LEVER TO APPLY DISC BRAKE



2. ROTATE PLATE TO LOCK LEVER IN POSITION



3. TO UNLOCK BRAKE, ROTATE PLATE BACK TO CENTRE POSITION SO BRAKE LEVER IS FREE TO MOVE

General riding

- **Uphill** - On steep climbs you can use the brakes to prevent roll back between pushes and make the climb easier. Simply push the drive levers, apply the brakes, bring the drive levers back, simultaneously release the brakes and push forwards. And repeat!
- **Downhill** - Take care to progress gradually and build confidence and experience on the flat before trying downhill's. Control your speed, try leaning back on steep descents and avoid turning sharply across a slope.
- **Braking** – The brakes are powerful yet controllable, only one finger is needed to apply them, take time to familiarise yourself with the brakes on the flat before attempting slopes. For good control, try dragging the brakes gently rather than grabbing them suddenly.
- **Steering** - At speed, only small movements are needed to make turns. Try to avoid sudden sharp turns at speed.

Have a great ride!

If you have any questions, please contact:
info@mountaintrike.co.uk or Tim on 07816 955 945